

# Blue Line Drilling Co., L.L.C.

Rig/Job #: <u>01-257</u>		<u>2900'</u>		Date: <u>5/24/17</u>	
Daily Report # <u>2</u>		Operator <u>MUS Producing</u>		Lease & well <u>University 3 #5</u>	
County <u>Crockett</u>		Move on <u>5/18/17</u>		Spud <u>5/23/17</u> Time <u>7:45 AM</u>	
Set surface <u>5/23/17</u>		Time <u>10:30 pm</u>		Drill out surface Time	
Days on location <u>7</u>		Days since spud <u>3</u>		Days out of surface	
Depth <u>900</u>		Operation <u>wait on cement</u>		Formation <u>surface</u> Rate <u>1 mpf</u>	
Pump press <u>300</u>		SPM <u>60</u>		RPM <u>70</u> WOB <u>13</u> 000#	
Vis <u>water</u>		Mud wt		Ph CI Water loss	
Mud(sx)		Lime <u>3</u>		Lignite Cedar Fiber	
Bar		MF55		PAC	
Caustic		Soda ash		Paper <u>31</u>	
Gel <u>50</u>		Starch		Polymer	
CS Halls		Supr trt		DMC\$ CMC\$	
Bit# <u>1</u>		Brand		Type <u>DS616D</u> Size <u>6'14</u> Ser# <u>A156264</u> Jets <u>6/14</u> Bit Hrs <u>14</u>	
Depth in <u>40</u>		Total footage <u>860</u>		Avg rate <u>64</u> fph Footage last 24 hrs <u>532</u>	
Bit#		Brand		Type Size Ser# Jets Bit Hrs	
Depth in		Total footage		Avg rate Footage last 24 hrs	
Downtime last 24 hrs		Cum downtime		Cum rig time	
Diesel on hand		Start <u>53</u> inches		2404 gallons	
		End		gallons	
		Used		gallons	
CSG <u>21</u>		Jts of <u>85/8</u>		Size Wt <u>885</u> Feet Set @ KB	
		Jts of		Size Wt Feet Set @ KB	
CMT 1st stage		Lead <u>200</u>		Sx <u>CLASIC</u> Additives <u>47.94 28cc 1/4 # 10</u>	
		Tail <u>200</u>		Sx <u>CLASIC</u> Additives <u>28cc 1/4 # 10</u>	
CMT 2nd stage		Lead		Sx Additives	
		Tail		Sx Additives	
Notes:					
Accidents Name Tour Type injury					
Doctor Yes / No ? Dr. Name Days since last acc LTA					
Deviation survey <u>.50</u> deg @ <u>497</u> ft. deg @ ft. deg @ ft.					
deg @ ft. deg @ ft. deg @ ft.					
deg @ ft. deg @ ft. deg @ ft.					
Time log			Details of operations		
From	To	Time	in sequence & remarks		
6:00	7:15	1'4	lay 8" + cement shot		
7:15	8:15	1	mud up pits		
8:15	9:15	1	TTH to drill surface		
9:15	12:45	3 1/2	drlg 368-469		
12:45	1:00	1/4	WLS 2 467		
1:00	6:15	5 1/4	drlg 467-900		
6:15	6:45	1/2	(8) sweeps		
6:45	7:15	1/2	TOH - run casing		
7:15	10:30	3 1/4	rig + run 8 5/8 casing		
10:30	11:00	1/2	rig casing crew + rig up cement		
Time log			Details of operations		
From	To	Time	in sequence & remarks		
11:00	12:00	1	Cement plug by 12 AM		
12:00	6:00	6	wait on cement		